

# D/F MACHINE SPECIALTIES, INC.

"MIG" AND "TIG" WELDING TOOLS

1750 Howard Drive, North Mankato, MN 56003
Phone: (507) 625-6200 Fax: (507) 625-6203
Email: sales@dfmachinespecialties.com
www.dfmachinespecialties.com

# REMOTE MOUNT DOCKING SPOOL®/WELD BODY COMBINATION accommodates WATER COOLED NOZZLES



# **INSTRUCTIONS** and **PARTS**

#### CONTENTS

	Page		Page
Introduction	3	Ordering Information	9
Current Tips/Gas Nozzles	4	Complete Assemblies	10
Disassembly/Assembly	5	Standard Assemblies	11
Model NCM - Parts	_	Standard 5" - Layout	12
Standard 5"	6	Series A 5" - Layout	13
Model NCM - Parts Series A Hi-Capacity 5"	7	Long Reach - Layout	14
Model NCM - Parts		Wire Feeder Adapters/Inlets	15
Long Reach	8		

#### **SAFETY**

Welding is not particularly hazardous when certain safety practices are followed. Anyone using this equipment should be thoroughly trained in safe welding practices. Failure to observe safe practices may cause serious injury.

For more information, refer to the following standards in their latest revisions and comply as applicable.

- 1. ANSI Standard Z49.1, SAFETY IN WELDING AND CUTTING obtainable from the American Welding Society, 2501 N.W. 7th St., Miami, FL 33125.
- 2. ANSI Standard Z41.1, STANDARD FOR MEN'S SAFETY TOE FOOTWEAR obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018.
- 3. ANSI Standard Z49.2, FIRE PREVENTION IN THE USE OF CUTTING AND WELDING PROCESSES obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018.
- 4. OSHA, SAFETY AND HEALTH STANDARDS, 29CRF 1910, obtainable from the U.S. Government Printing Office, Washington, D.C. 20402.
- 5. AWS Standard A6.0, WELDING AND CUTTING CONTAINERS WHICH HAVE HELD COMBUSTABLES obtainable from the American Welding Society, 2501 N.W. 7th St., Miami, FL 33125.
- 6. NFPA Standard 70-1978, NATIONAL ELECTRICAL CODE obtainable from the National Fire Protection Association, 470 Atlantic Avenue, Boston, MA 02210.
- 7. ANSI Standard Z88.2, "Practice for Respiratory Protection" obtainable from the American National Standards Institute, 1430 Broadway, New York, NY 10018.
- 8. ANSI Standard Z87.1, SAFE PRACTICES FOR OCCUPATION AND EDUCATIONAL EYE AND FACE PROTECTION obtainable from the American National Standards Institute, 1430 Broadway, New York, NY, 10018.
- 9. NIOSH, SAFETY AND HEALTH IN ARC WELDING AND GAS WELDING AND CUTTING obtainable from the Superintendent of Documents, U.S. Printing Office, Washington, D.C. 20402.
- 10. American Welding Society Standard AWSF4.1 "Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping That Have Held Hazardous Substances", obtainable from the American Welding Society, 2501 N.W. 7th St., Miami, FL 33125.

#### INTRODUCTION

This manual covers Remote Mount Water Cooled Nozzles which offer a concept with interchangeability of Models for Mechanized "MIG" Welding. The Water Cooled Nozzles accommodate a wire diameter range of .030" - 1/16" hard wires, .035" - 7/64" tubular wires, and 3/64" - 3/32" soft wires.

The equipment consists of four (4) basic components: a utility station, an intermediate utilities combination assembly, a Remote Mount Docking Spool body, and a Water Cooled Nozzle. The Remote Mount Docking Spool body is the principal component in this welding equipment arrangement. It accepts the utilities at the top end of the spool and provides a means of accepting the nozzle assembly at the lower end. In addition, several other features important to a welding system are provided. Incorporated within the water chamber of the Docking Spool body are check valves which provide a means of retaining the residual water in the lines when the nozzle is removed from the Docking Spool body. Also, a Posit ring is provided to allow positive location at the mounting bracket to achieve dimensional stability.

These welding assemblies are designated by Models. Three (3) are illustrated in the parts breakdown lists. The Model NCM covered herein has a current capacity of 450/600 amperes in argon shielding. These accommodate slip-in current tips fastened by a collet action nut. This arrangement increases the versatility of the equipment by allowing tip extension beyond the gas nozzle where critical access problems to the weld area are encountered. The wire diameter with hard wire is .030" - 1/16", cored wire .035" - 7/64", and aluminum wire diameter range of 3/64" - 3/32".

Page 9 lists the complete equipment assemblies.

On page 10 and 11 the standard arrangement with a utility station is shown.

### IMPORTANT

Make certain the cooling water supply is at least the flow rate of 5 pints per minute at 50 psi (80 psi maximum). Gun ratings are affected by shielding gas used, arc time, cooling time, and inlet water temperature. Water outlet temperatures should not exceed  $120^{\circ}$  F.

To obtain maximum performance with this water cooled equipment a water circulator of the heat exchanger type with a heat displacement of 30,000 BTUs at 72° F should be used.

### **CURRENT TIPS - TABLE I**

## CURRENT TIPS - 1/4" DIAMETER SLIP-IN

	WIRE SIZE	WIRE TYPE	CODE NO.	
	.030"	Hard	10787	
	.035"	Hard	10788	
	.045"	Hard	10789	
	.052"	Hard	10830	
	1/16"	Hard	10790	
	3/64"	Aluminum	10781	
	1/16"	Aluminum	10782	
	3/32"	Aluminum	10783	
(Bent)	3/64"	Aluminum	15176	
	1/16"	Aluminum	15177	

### CURRENT TIPS - 5/16" DIAMETER SLIP-IN

	WIRE SIZE	WIRE TYPE	CODE NO.
(Tip provides 1/8" set back)	.030"	Hard	10883
	.035"	Hard	10884
	.045"	Hard	10885
	.052"	Hard	10886
	1/16"	Hard	10887
	5/64"	Hard	10888
	3/32"	Hard	10889
(Tip provides 3/8" set back)	.035"	Cored	10893
	.045"	Cored	10894
	.052"	Cored	10895
	1/16"	Cored	10896
	5/64"	Cored	10897
	3/32"	Cored	10898
	7/64"	Cored	10899
(Tip provides 1/8" set back)	3/64"	Soft	10902
e Pota dravaca de variencia de Primo Villa da	1/16"	Soft	10903
	3/32"	Soft	10904

## GAS NOZZLE - TABLE II

REF.	CODE NO.	7	TYPE		I.D.
1	10362	Copper	Tapered	15/16"	5/8"
2	10340	Copper	Straight	1"	3/4"
3	10359	Copper	Tapered	15/16"	5/8"
4	10374	Copper	Straight	5/8"	7/16"









# GAS NOZZLE - TABLE III - Water Cooled Nozzles - Series A

REF.	CODE NO.		TYPE		I.D.
1	16749	Copper	Short Taper	1 3/8"	11/16"
	16750	Copper	Short Taper	1 3/8"	13/16"
1.18	16751	Copper	Short Taper	1 3/8"	15/16"
2	18030	Copper	Full Taper	1 3/8"	11/16"
	18031	Copper	Full Taper	1 3/8"	13/16"
	18032	Copper	Full Taper	1 3/8"	15/16"





2

#### DISASSEMBLY

To remove the Water Cooled Nozzle from the DOCKING SPOOL/Weld Body Combination, proceed as follows:

- 1. Remove the forward gas nozzle (when used).
- Unscrew the collet nut with wrench supplied. Wrench is also used to remove 7/16" threaded tips.
   This will allow removal of the tip and support tube/spatter disc arrangement.
- Unscrew the fastening nut which applies the water cooled nozzle assembly to the DOCKING SPOOL/ Weld Body Combination. The water cooled nozzle may now be pulled from the DOCKING SPOOL/ Weld Body Combination.
- 4. The water transfer fittings may be removed from the water cooled nozzle with a 7/16" open end wrench. Following this the insulating collar may be removed.
- If the tip adapter in the DOCKINIG SPOOL/Weld Body Combination should be worn or damaged proceed as follows:

Two 1/2" open end wrenches are needed to remove the adapter/jam nut assembly from the DOCKING SPOOL/Weld Body Combination. Break jam nut loose first, and then remove assembly.

#### ASSEMBLY

- Apply proper tip adapter to DOCKING SPOOL/Weld Body Combination.
  - a. Fully tighten adapter until securely seated.
  - Using two 1/2" open end wrenches, firmly tighten jam nut to lock adapter to assembly.
- The nylon collar should be placed over the fittings on the rear of the water cooled nozzle assembly.
   It is important that the collar alignment indication hole (viewed from the rear of the nozzle) align with the small concave mark provided on the collar of the water cooled nozzle. Apply the water transfer fittings to the fittings provided on the water cooled nozzle.
- 3. The nozzle assembly may now be applied to the DOCKING SPOOL/Weld Body Combination. For proper orientation of the water fittings to the channels provided in the DOCKING SPOOL/Weld Body Combination it is extremely important that the indicator hole in the collar align with the small concave mark provided on the face of the DOCKING SPOOL. This alignment will allow the water cooled nozzle to be pushed up into the DOCKING SPOOL after which the nut may be applied.
- 4. The insulation tube should now be placed in the water cooled nozzle. This should be followed by applying the spatter disc. When spatter disc (10405) is replaced make certain that the counterbored end is facing the Weld Body. Replacement of spatter disc/support tube is accomplished by sliding the spatter disc (18253) into the water cooled nozzle, followed by pushing the support tube up into the water cooled nozzle. Apply the current tip and replace gas nozzle.


#### SPARE PARTS

It is recommended that the spare parts in Table 1 be on hand to assure minimum downtime.


ITEM	CODE NO.	MIN. QUANTITY
Adapter Assembly	To Be Selected	1
Body Liner	To Be Selected	2
Insulation Tube	To Be Selected	1
Water Cooled Nozzle	To Be Selected	1
Spatter Disc	To Be Selected	2
Current Tip	To Be Selected	5
Gas Nozzle	To Be Selected	2

# REMOTE MOUNT DOCKING SPOOL® / WELD BODY COMBINATION


MODEL-NCM (SLIP-IN TIP) WATER COOLED NOZZLE LONG 5"



REF.	CODE NO.	DESCRITPION
1	14715	Socket Set Screw.
2	45157	DOCKING SPOOLWeld Body Combination
3	40022	Spring
4	40023	Ball
5	40024	Seat
6	13883	Socket Set Screw
7	11860	Jam Nut
8	12023	Adapter Assembly-1/4"Slip-In Tip
	18313	Adapter Assembly-5/16 Slip-In Tip
9	SIGNACULAR CONTRACTOR	
10		
11	45880	Body Liner .030"035"
	45881	Body Liner .035"045"
	45882	Body Liner .045"-1/16"
	45892	Body Liner 5/64"-3/32"
	45893	Body Liner 7/64"-1/8"
	45883	Body Liner 3/64"AL
	45884	Body Liner 1/16"AL
	45885	Body Liner 3/32"AL
12	13921	'O" Rings (4 req'd)
13	40025	Transfer Fitting
14	13912	Internal "O" Ring
15	40010	Insulating Collar
16	12516	External "O" Ring
17	45103	Water Cooled Nozzle-Long 5"
18	12303	Insulation Tube
19	40001	Nut
20	10405	Spatter Disc
21	11950	Collet Nut-For 1/4"Slip-In Tip
	18262	Collet Nut-For 5/16"Slip-In Tip
22	W. Contract	Current Tips-see table IV
23		Gas Nozzles-see table II
24	12111	Wrench
25	14610	Nozzle Thread Chaser Tap
26	40026	POSIT Ring









# REMOTE MOUNT DOCKING SPOOL® / WELD BODY COMBINATION MODEL-NCM (SLIP-IN TIP) WATER COOLED NOZZLE

HI-CAPACITY SERIES-A 5"




REF.	CODE NO.	DESCRITPION
1	14715	Socket Set Screw.
2	45157	DOCKING SPOOL/Weld Body Combination
3	40022	Spring
. 4	40023	Ball
5	40024	Seat
6	13883	Socket Set Screw
7	11860	Jam Nut
8	12023	Adapter Assembly-1/4"Slip-In Tip
	18313	Adapter Assembly-5/16*Slip-In Tip
9	13921	"O" Rings (4 req'd)
10	40025	Transfer Fitting
11	45880	Body Liner .030"035"
	45881	Body Liner .035"045"
	45882	Body Liner .045"-1/16"
	45892	Body Liner 5/64"-3/32"
	45893	Body Liner 7/64"-1/8"
	45883	Body Liner 3/64*AL
	45884	Body Liner 1/16"AL
	45885	Body Liner 3/32"AL
12	13912	Internal "O" Ring .
13	40010	Insulating Collar
14	12516	External "O" Ring
15	45127	Water Cooled Nozzle Series-A 5" Noz.
16	18383	Insulation Tube
17	40003	Nut
18	18253	Spatter Disc
19	18252	Support Tube
20	11950	Collet Nut-For 1/4"Slip-In Tip
	18262	Collet Nut-For 5/16"Slip-In Tip
21		Current Tips-see table IV
22	-740-FC V 6-74	Gas Nozzies-see table III
23	12111	Wrench .
24	14614	Nozzle Thread Chaser Tap
25	40026	POSIT Ring






# REMOTE MOUNT

# DOCKING SPOOL® / WELD BODY COMBINATION MODEL-NCM (SLIP-IN TIP) WATER COOLED NOZZLE LONG REACH




Ref.	Code No.	Description
1	14715	Socket Set Screw.
2	45157	DOCKING SPOOLWeld Body Combination
2 3	40022	Spring
4	40023	Ball
5	40024	Seat
6	13883	Socket Set Screw
7	13921	"O" Rings (4 req'd)
8	11960	Jam Nut
9	40025	Transfer Fitting
10	45900	Body Liner .030"035" H/C
	45901	Body Liner .035"045" H/C
	45902	Body Liner .045"-1/16" H/C
	45909	Body Liner ,5/64"-1/8" C
	45903	Body Liner 3/64" AL
	45904	Body Liner 1/16" AL
	45905	Body Liner 3/32" AL
11	13912	Internal "O" Ring
12	40010	Insulating Collar
13	12516	External "O" Ring
14	18241	Adapter .030"-1/16" For 1/4" Slip-InTip Adapter 3/64"-3/32"AL For1/4" Slip-InTip
	18367	Adapter .030"-7/64" For5/16" Slip-In Tip
15	45107	Water Cooled Nozzle-Strd Long Reach
16	18108	Insulation Tube
17	40001	Nut
18	10405	Spatter Disc
19	11950	Callet Nut-For 1/4" Slip-In Tip
1112	18262	Collet Nut-For 5/16" Slip-In Tip
20	211 THILL CARGACA	Current Tip-See Table IV
21		Gas Nozzle-See Table II
22	12111	WRENCH
23	14610	Nozzle Thread Chaser Tap
24	40026	POSIT Ring




# ORDERING INFORMATION: COMPLETE ASSEMBLIES Advise Wire Diameter and Feeder Manufacturer

	Complete Assembly- Consists of Water Cooled Nozzle, DOCKING SPOOL, and Utility Combination			
WATER COOLED NOZZLES	MODEL-NCM			
WATER COOLED NOZZLE	40753-11-6			
SERIES-A 5"	11 FT, UTILITIES			
HI-CAPACITY	6 FT. CASING			
	40754-11-7			
	11 FT. UTILITIES			
	7 FT, CASING			
WATER COOLED NOZZLE	40755-11-6			
LONG - 5" STRD.	11 FT. UTILITIES			
	6 FT, CASING			
	40756-11-7			
	11 FT. UTILITIES			
	7 FT, CASING			
WATER COOLED NOZZLE	40201-11-6			
LONG REACH	11 FT. UTILITIES			
	6 FT. CASING			
	40202-11-7			
	11 FT. UTILITIES			
	7 FT. CASING			




# REMOTE MOUNT DOCKING SPOOL® / WELD BODY COMBINATION WATER COOLED NOZZLE ASSEMBLIES



NOTE: SPECIFY WIRE DIAMETER, GAS NOZZLE AND CURRENT TIP (Page 2).

REF.	CODE NO.	DESCRIPTION		
1	45157	DOCKING SPOOL/Weld Body Combination		
2	48202	W/C Nozzle Assembly 5"		
3	48264	W/C Nozzle Assembly Series-A 5"		
4	48220	W/C Nozzle Assembly Long Reach		

# STANDARD ASSEMBLIES



REF.	CODE NO.	DESCRIPTION	REF.	CODE NO.	DESCRIPTION
1	46350	CASING .030"035" (REQUIRES Liner)	7	46624-11-6	5/64*-3/32*(Single Piece Casing)
	46370	CASING .035"-1/16"(REQUIRES Liner)		46624-11-7	5/64*-3/32*(Single Piece Casing)
	46420	CASING .035"045" SINGLE PIECE		46625-11-6	7/64*-1/8*(Single Piece Casing)
	46440	CASING .045"-1/16" SINGLE PIECE		46625-11-7	7/64*-1/8*(Single Piece Casing)
	46460	CASING 5/64"-3/32" SINGLE PIECE	8	45196	UTILITY STATION
	46480	CASING 7/64"-1/8" SINGLE PIECE	9	253555	FEEDER ADAPTER
2	46300	WATER IN HOSE ASSEMBLY	10	Service -	INLET
3	14803	CLAMP	11	47020	LINER .030"035" HARD/CORED
4	46320	WATER OUT HOSE & POWER CABLE ASSY.		47021	LINER .035"-,045" HARD/CORED
5	46260	GAS HOSE ASSEMBLY		47022	LINER .045"-1/16" HARD/CORED
6	46630	CABLE/HOSE SHEATH		47023	LINER 3/64" SOFT
7		UTILITY COMBINATION-CONSISTING OF		47024	LINER 1/16" SOFT
	V ii	ITEMS 1,2,3,4,5,6 &11		47025	LINER 3/32" SOFT
	46620-11-6	.030"035"(With 46350-6 Casing)			
	46620-11-7	.030*035*(With 46350-7 Casing)	1		
	46621-11-6	.035"-1/16"(With 46370-6 Casing)	1		
	46621-11-7	.035"-1/16"(With 46370-7 Casing)			
	46622-11-6	.035"045"(Single Piece Casing)			
	46622-11-7	.035"045"(Single Piece Casing)			1
	46623-11-6	.045*-1/16"(Single Piece Casing)			
	46623-11-7	.045"-1/16"(Single Piece Casing)			

ORDERING INFORMATION:Add footage digit to code number to obtain single items such as hoses, casings, liners or sheaths.

Utility combinations are obtained by Code No. as listed


# ROBOTIC MACHINE BARREL LAYOUT

REMOTE MOUNT

DOCKING SPOOL® / WELD BODY COMBINATION

MODEL NCM (SLIP-IN TIP)

W/C NOZZLE 5"




# ROBOTIC MACHINE BARREL LAYOUT

REMOTE MOUNT

DOCKING SPOOL® / WELD BODY COMBINATION


MODEL NCM (SLIP-IN TIP)

W/C NOZZLE SERIES-A 5"



# ROBOTIC MACHINE BARREL LAYOUT

# REMOTE MOUNT DOCKING SPOOL®/ WELD BODY COMBINATION MODEL NCM (SLIP-IN TIP) LONG REACH NOZZLE





# WIRE FEEDER ADAPTERS AND WIRE INLETS

Manu-			Remote Adapter			Direct Mount Adapter	
facturer	Models	Wire Diameter	Hard or Al	Cored	*Stub	Hard or Al	Cored
Airco	AHF-T AHF-N AHF-R1 AFH-U1 AHF-V1 AHF-V6 AHF-NP AHF-N6	.030"035 Hard .045"-1/16" Hard 3/64" Soft 1/16" Soft 3/32" Soft 5/64"-3/32" Cored 7/64" Cored	13031 13031 13031 13031 13031	13029 13029	16166 16167 16654 16655 16656 16168 16169	13032 13032 13032 13032 13032	13028
Airco	System I/II Wire Guide	Shaft & Spool Assy. Code No. 18209 (Requires Q.D. Socket & Plug— 12981 Assy. & Wire Guide) .030"035" .035"045" 3/64" AL 1/16" AL			18238 18210 18212 18213		
Compak- O-Matic	480, 120, 125	.035"045" Hard .045"-1/16" Hard 3/64" Soft 1/16" Soft 3/32" Soft 5/64"-3/32" Cored 7/64" Cored	13486 13486 13486 13486 13486	16612 16612	16690 16691 16694 16695 16696 16692 16693	13485 13485 13485 13485 13485	16611 16611
	No. 75	.035" Hard .045" Hard 1/16" Hard 3/64"-1/16"- 3/32" AI 5/64"-3/32" Cored 7/64" Cored	13482 13488 13489 13490 13491 13492			13487 13488 13489 13490	13491 13492
Esab			18246	18247		18248	18249
Hobart	All Models	.030".035" Hard .035".045" Hard .045"-1/16" Hard 3/64" Soft 1/16" Soft 3/32" Soft (5/64"-7/64") Cored	13067 13067 13067 13067 13067 13067	16087	16665 16666 16667 16670 16671 16672	13068 13068 13068 13068 13068 13068	16225
Lincoln	LN-7 LN-8 NA5-R	.035"045" Hard .045"-1/16" Hard 3/64" thru 3/32" AI 5/64"-3/32" Cored 7/64" Cored	13110 13110 13111	13112 13112	16698 16699 16700 16701	13110 13110 13111	13112 13112
Water Cooled Guns	LN-9	.035"045" Hard .045"-1/16" Hard 5/64"-3/32" Cored 7/64" Cored	16581 16581	16582 16582	16711 16712 16713 16714	16528 16528	16529 16529
	NA3 NA5	.035"045" .045"-1/16" 5/64"-7/64"	13113 13113 16879		16882 16883 16885	16880 16880	16881
	Power - Feed 10	5/64" - 1/8" 0.30" - 0.62"		13469		13468	

	YW50AKW1	0.30" - 1/16"	13466				
Panasonic	PME-12X	0.30" - 1/16"	13090	Requires Inlet			
отс	Requires Insert Requires Insert	.030"035" .035"045" .045"-1/16" 5/64"-7/64" .030"035" .035"045" .045"-1/16" 5/64"-7/64"	18268		18270 18271 18273 18274 18277 18278 18280 18281	18275	
Miller ("50" Series)	S-52A S-52E S-54E S-52D S-54D D-52D	.030"035" Hard .035"045" Hard .045"-1/16" Hard 3/64" Soft 1/16" Soft 3/32" Soft 5/64"-3/32" Cored 7/64" Cored	16557 16557 16557 16557 16557 16557	16559 16559	16673 16674 16675 16679 16880 16681 16676 16677	16558 16558 16558 16558 16558 16558	16560 16560
	SWM11 SWM113 SWM23 SWM25 EH35 EH10	.035"045" Hard .045"-1/16" Hard 3/64" Soft 1/16" Soft 3/32" Soft 5/64"-3/32" Cored 7/64" Cored	13043 13043 13043 13043 13043	13052 13052	16690 16691 16694 16695 16696 16692 16693	13080 13080 13080 13080 13080	13079
	SWM38 EH8	D/F Insert .035"045" Hard .045"-1/16" Hard 5/64"-3/32" Cored 3/64"-1/16" Al	13047 13048 13050	13049		13047 13048 13050	13049
facturer	SWM31 SWM34 SWM37	Casing to Feeder (Accepts Linde Outlet Guide)	13046			13046	
		Wire Diameter	Hard or Al	Cored	*Stub Liner	Hard or Al	Cored
Manu-			Remote Adapter			Direct Mount Adapter	

<sup>\*</sup>Stub liners only required in feeder adapter when single piece casing is used.

#### FEEDER ADAPTER INLETS

Wire Size	Steel Code No.	Brass Code No.	Nylon Code No	
.030"	13801	16417		
.035"	13803	16418		
.045"	13806	16419		
.052"	13844	16420		
1/16"	13809	16421		
5/64"	13812	16422		
3/32"	13814	16422		
7/64"	13816	2340,000		
1/8"	13842			
3/64" AI.	1,000(200)		13807	
1/16" AL			13810	
3/32" Al.			13815	

#### PANASONIC INLETS

Wire Size	Steel Code No.	Brass Code No.	Nylon Code No.	
.030"	19609	19600		
.035"	.035" 19610 19601			
.045"	.045" 19611 19602			
.052"	.052" 19612 19603			
1/16"	1/16" 19613 19604			
5/64"	5/64" 19614 19605			
3/32"	19615	19606		
7/64"	19616			
1/8"	19617			
3/64" AL			13807	
1/16" AL			13810	
3/32" AL			13815	

#### WARRANTY

This Equipment is sold by D/F Machine Specialties, Incorporated, under the warranty set forth in the following paragraph. Such warranty is extended only to the buyer who purchases the equipment directly from D/F or its authorized distributor as new merchandise.

The barrel and cable assemblies are warranted by D/F to be free from manufacturing defects for 90 days after delivery by D/F, provided that the equipment is properly operated under conditions of normal use and that regular periodic maintenance and service is performed. Expendable parts are not warrented for any specific time. Expendable parts referred to herein would be the nozzles, current tips, spatter discs, insulators, casing liners, and wire inlets. D/F's sole obligation under this warranty is limited to making replacement at its manufacturing facility for barrel assemblies which are returned to it with transportation charges prepaid, and upon D/F's examination have been found to be so defective.



Phone: (507) 625-6200 Fax: (507) 625-6203 Email: sales@dfmachinespecialties.com www.dfmachinespecialties.com